


Basic alarms

Burner fault
Unbalanced burning
Regular maintenance for Burner
Water pump circulation fus activated
Thermostat limit switch activated
Min. gas pressure switch activated



Optional alarms / functions

Low inlet water temperature
High smoke temperature
Low water indicator tripped
Oil level low
Oil leak
Oil consumption remote readings
Burner operating status readings